

**Shark**

**Bare Floor Nozzle**  
Assembly Instructions

## Navigator<sup>™</sup> Lift-Away<sup>™</sup>

- 1 From the Upright Vac mode, press the release button on the lower side of the canister and remove the motorized floor brush. Place the bare floor nozzle on a level floor surface, align the tube of the floor nozzle with the tube on the detachable canister and click into place. (Fig. 1)

**OR**

With the canister removed, insert the extension wand and handle directly onto the bare floor nozzle. (Fig. 2)

- 2 Press the On/Off switch to the "I" position to turn the suction motor on.




Fig. 1




Fig. 2

**Ideal for bare floor cleaning and large and small particle pick up. Low profile for easy access to any area.**



TOLL FREE: 1-800-798-7398

[www.sharkclean.com](http://www.sharkclean.com)



K



PMS 2592

XSN350W  
Care Instructions  
270.9gsm white offset cover stock